

NEENAH COLDENHOVE

DARK INKJET HEAT TRANSFER PAPER

For commercial and hand iron use



Produced with: 3G JET OPAQUE®



Produced with: JET OPAQUE® II



Produced with: 3G+JET OPAQUE®



MADE IN USA


JET-PRO® Brands

For transfer to dark colored fabrics, mousepads, coasters, puzzles, and leather goods.

3G JET OPAQUE® (9838P0) and JET OPAQUE® II (9754P0) Heat Transfer Papers are printable by most desktop and roll fed inkjet printers and is easy to use for transferring inkjet photo-quality images or other graphics to dark colored materials, offering a soft, supple transferred image that is vibrant and durable – and will withstand many laundry cycles.

- Image can be plot cut or trimmed
- Image should be printed **RIGHT-READING**


HEAT
RIGHT-READING



3G+JET OPAQUE® (9885P0) Transfer Paper is printable by most desktop and roll fed inkjet printers and is easy to use for transferring inkjet photo-quality images or other graphics to dark colored materials, offering a soft, supple transferred image that is vibrant and durable – and will withstand many laundry cycles.

- Image can be plot cut or trimmed
- Works well with lifting tapes
- Image should be printed **RIGHT-READING**

HEAT
RIGHT-READING



NEENAH COLDENHOVE Brands for Inkjet Printers	Product ID	Natural & 50/50 Fabric	Poly Fabric	Hard Surface	Mesh Screen 85-230	Works well with Photos	Certified for HP Indigo Presses	Prepress*	Peel Temperature				Cover with Parchment	Repress and Stretch	Weedable
									Hot	Warm	Cold	Hand Iron			
JET-PRO® SS (Soft Stretch)	9811P0	✓	★	★		✓		✓	✓	✓	✓	✓	•	•	
3G JET OPAQUE®	9838P0	✓	★	★		✓		✓			✓	✓	✓		★
JET OPAQUE® II	9754P0	✓	★	★		✓		✓			✓	✓	✓		★
JET-PRO® ACTIVE WEAR	9830P0		✓			✓		✓	✓			✓			
3G+JET OPAQUE®	9885P0	✓	★	★		✓		✓			✓	✓	✓		✓

✓ Yes [✓ If, • Then] ★ With special settings, dictated by the design



*Prepress to remove wrinkles and moisture.

3G JET OPAQUE®, JET OPAQUE® II, and 3G+JET OPAQUE®

PRINTING:	<ol style="list-style-type: none">1. Print image on coated side of paper right reading (do not mirror the image).2. Trim away the unprinted areas of the transfer if desired.
PRE-TRANSFERRING:	Prepare the garment/fabric by ensuring the surface is clean, dry, and wrinkle free using a lint brush and your heat press.
TRANSFERRING:	<ol style="list-style-type: none">1. Bend a corner to remove the backing paper from the printed image.2. Place the Heat Transfer Paper on the top of the garment with the image facing up (right reading to you).3. Completely cover the image with one sheet of parchment paper.4. For Cotton: Press for 30 seconds at 350°F/177°C using medium pressure (30 to 45 psi/2 to 3 bar). For 50/50, Polyester/Cotton: Press for 30 seconds at 300°F/149°C using medium pressure (30 to 45 psi/2 to 3 bar). For 100% Polyester: Press for 30 seconds at 275°F/135°C using medium pressure (30 to 45 psi/2 to 3 bar).5. Once cold, peel away ironing sheet in a smooth even motion.
WASHING:	Turn garment inside out and wash in cold water using a mild detergent. Do not use bleach. Dry on low-heat setting. If you intend to iron the transferred area, ensure that the image is covered with parchment paper before ironing.
STORAGE AND HANDLING:	Store Heat Transfer Paper in a cool, dry area and do not remove from carton or poly bag until you are ready to use.

IMPORTANT: Printers and heat presses vary in accuracy. We have tested our products with numerous printers and presses with excellent results. Nonetheless, we recommend that you test the paper in your equipment to ensure the best results. Neenah's maximum obligation shall be to replace any paper that has proven to be defective.

3G JET OPAQUE®, JET OPAQUE® II, and 3G+JET OPAQUE®

PRINTING:	<ol style="list-style-type: none"> 1. Print image right reading using a laser printer on the heaviest paper weight setting. 2. Trim away the unprinted areas of the transfer if desired.
PRE-TRANSFERRING:	<ol style="list-style-type: none"> 1. Preheat iron to the hottest setting – do NOT use steam (empty all water). 2. Iron on a waist high, smooth, and heat-resistant hard surface. Do NOT use an ironing board. 3. Place a pillowcase on the surface and iron the pillowcase to remove all wrinkles. 4. Place garment/fabric on pillowcase and iron it to remove all wrinkles. 
TRANSFERRING:	<ol style="list-style-type: none"> 1. Place the image on top of the garment with image facing up (right reading to you). 2. Completely cover the image with parchment paper. 3. Using two hands and heavy pressure, slide the iron up and down (vertically) over the entire image area for 45 seconds. 4. Rotate T-shirt with transfer and parchment paper still intact 90° and iron up and down (vertically) over the entire image area for an additional 45 seconds. 5. Repeat step 4 two more times for a total of 3 minutes ironing (for A4/Letter). 6. Let the transfer cool completely and then peel the parchment paper away from the image. <p>Note. Please use the below table for various size transfers. If the transfer area is smaller than the iron, iron for 45 seconds with heavy pressure.</p> 
WASHING:	Turn garment inside out and wash in cold water using a mild detergent. Do not use bleach. Dry on low-heat setting. If you intend to iron the transferred area, ensure that the image is covered with parchment paper before ironing.
STORAGE AND HANDLING:	Store Heat Transfer Paper in a cool, dry area and do not remove from carton or poly bag until you are ready to use.

PAPER SIZES AND IRONING TIMES

Approximate paper size:	Ironing time, each direction:
8.5" x 11" (Letter) or A4	45 seconds
5.5" x 8.5" or A5	25 seconds
4" x 11"	15 seconds
11" x 17" (Tabloid) or A3	45 seconds on the first half, then 45 seconds on the second half. Do not move between ironings (6 minutes total).



www.conde.com • 800-826-6332

