

# Water Slide Light for Color Laser

## Application Instructions

### NOTES

#### Recommended Materials

White or Light Colored  
Candles  
Glass  
Metal  
Wood  
Soap

#### Accessories Required

Computer, Color Laser  
Printer, Large Water  
bowl, Dish Soap, Plain  
Paper, Plastic bag or  
plastic wrap.

#### Printable side

The printable side is  
the white glossy coated  
side.

#### Storage

Paropy CL Water Slide  
has an indefinite shelf  
life when stored at  
room temperature.  
Keep away from direct  
heat, sunlight, and  
humidity.

#### Tips

For extra durability on  
candles, we suggest  
using a glue stick to  
help adhere the WT  
transfer paper.

The candle can also  
be heated with a blow  
dryer to soften the wax  
before applying the  
transfer.

**Water Slide Light** will allow image transfer to objects that cannot be heated with a commercial heat press. Substrate must be white or light-colored to use this product. If your substrate is dark, Condé recommends using Water Slide DARK for image decoration.

This paper will work in most Oil-Based and Non-Oil Laser Copiers and Printers. It is recommended that feed this paper through your Bypass or Multi-Purpose Paper Tray. If transfers jam within the fuser assembly of your color laser printer, discontinue use immediately.

#### Step 1

Feed transfer paper into laser printer so that the printer is printing on the printable side (white glossy coated side). It is recommended to use the bypass tray when printing.

#### Step 2

Design your image and and resize if necessary. Do not mirror image the design

#### Step 3

Trim the imaged Water Slide paper as close as possible without cutting into image using scissors/exacto knife.

#### Step 4

Fill suitable sized bowl with water and add about 5-10% liquid dish soap.

#### Step 5

Wet the plastic bag/wrap and set to one side. Then place the imaged paper in bowl for 5-10 seconds.

#### Step 6

Put wet WT paper on plastic bag/wrap face down. Absorb excess water with a plain piece of paper.

#### Step 7

Gently remove paper backing from plastic bag/wrap. Place the imaged plastic bag/wrap on top of material to be printed. With sponge and finger, gently correct position of image and iron out air bubbles.

#### Step 8

Let the transfer and material dry for at least 1 hour before handling.

For tutorial videos on this product, visit

